




Programming Primus



manual temperature setting in program 0 (no program)



Cleaningprogramme



Legend Information Field

SEr	Service intervals in months. (0-36)
CO	Code input for Service only.
Sign	Audible signals of the base setting on (1) or off (0)
FEST	Enter/input of time of fat use in hours (0-100)
FEMI	Enter/input of time of fat use in minutes (0-59)
Food	Setting of time for transition in standby mode (0-59)
Pr	Selection of the program number
tE	Setting of temperature
Ft	Frying time in minutes (0-29)
FtS	Frying time in seconds (0-59)
St	Shaker time in minutes (0-29)
StS	Shaker time in seconds (0-59)
EndA	End action after finishing of the frying process (Si-Signal) when 0 is entered the actuator is deselected and not in function

The time of fat use is a time value determined by the client, which states nothing about the level of perishability of fat. Therefore, we recommend to use appropriate means, e.g. fat test devices.